

Aufbauanleitung "SENTINO 3000": Hängeaufsatz 5223 L/R

VENJAKOB


Das mitgelieferte Befestigungsmaterial (Dübel und Schrauben) ist ausschließlich für die Befestigung von Bauteilen an Beton und/oder festem Mauerwerk geeignet. Bitte beachten Sie auch bei den Wandmontageelementen die max. Belastungswerte. Die Wandbeschaffenheit ist idealerweise bei Auftragserfassung zu erfragen und spätestens vor der Montage unbedingt von fachkundigem Personal zu prüfen. Bei abweichender Beschaffenheit (z.B. Leichtbauwänden) ist eine andere, der Belastung angemessene Befestigung bauseits vorzunehmen. Klären Sie elektrische Vorleistungen für Anschluss- und Gerätetechnik. Frei hängende Beleuchtungen erfordern Kabelkanallösungen auf oder unter Putz.

1. Die genaue Position des Hängeaufsatzes ist abhängig vom darunter- bzw. nebenstehenden Möbel.
 2. Bohrmaße für Aufhängeschienen gemäß Abb. 2 an die Zimmerwand übertragen. Bohrung $\varnothing 8\text{mm}$ in das Mauerwerk bohren und Kunststoffdübel $\varnothing 8 \times 51\text{mm}$ (Teile-Nr.50802) einsetzen. Aufhängeplatte (Teile-Nr.50427) mit 3x Schraube $\varnothing 5 \times 50\text{mm}$ (Teile-Nr.00055) anschrauben.
- Achtung: Aufhängeplatte = Set \rightarrow Mittig an Sollbruchstelle knicken für linke und rechte Aufhängeplatte!
3. Sofern für die Montage erforderlich: Frontteile ausbauen.
 4. Im Korpus die untere Schraube (Aushängesicherung gemäß Abb. 1) am Hängebeschlag öffnen, Korpus an die Zimmerwand hängen und Aushängesicherung wieder schließen.

Ausrichtung mit Wasserwaage über folgende Schritte mit Kreuzschraubendreher Größe PZ2 (siehe auch Abb. 1):

5. Eine horizontale Korrektur ist mit der oberen Höhen-Stellschraube am Hängebeschlag vorzunehmen.
6. Mit der mittleren Tiefen-Stellschraube den Abstand zur Zimmerwand bzw. die vertikale Neigung einstellen.
7. Die Ausklinkungen in der Rückwand mit Abdeckkappen verschließen. Frontteile wieder einbauen und ggf. ausrichten.
8. Griffe montieren, hierfür Griffschrauben M4x23mm (Teile-Nr. 51251) verwenden.



Achtung: Alle Beschläge aus Gründen der Tragfähigkeit gleichmäßig ausrichten und belasten!

Maximale Belastbarkeit der Hängetypen beachten!

Bei nicht sachgerechter Montage gemäß Montageanleitung droht ein unbeabsichtigtes Herabfallen der Möbel.



Abbildung 1: Verstellung & Aushängesicherung Hängebeschlag






Abbildung 2: Bohrmaße von Außen- bzw. Oberkante Korpus für Aufhängeschienen

Alle Angaben in mm!



Hängebeschläge nur im
äußeren Klappenfach



Assembly instructions "SENTINO 3000":

VENJAKOB



Hanging cabinet 5223 L/R

The fixture materials provided with this product (dowels and screws) are only suitable for fixing parts to concrete and/or solid masonry. Please observe the maximum load that the wall-mounted elements can carry. Ideally, the suitability of the wall should be enquired about when the order is made and must be checked by specialist staff before the cabinet is assembled at the latest. If the condition of the wall is not suitable (e.g. if it is a lightweight partition wall), then another type of fixture suitable for the load that is to be carried should be used. Check the electrical input of any connection or device technology. Free-hanging light fixtures require cable duct solutions that are either on or under plaster.

1. Define the exact position for the cabinet on the wall which depends on the item down the unit.
2. Transfer the drilling dimensions for suspension rails to the room wall in accordance with fig. 2. Drill a hole $\varnothing 8\text{mm}$ in the masonry and insert the plastic dowel $\varnothing 8 \times 51\text{mm}$ (Part No.50802). Secure the suspension plate (Part No.50427) with 3x panhead screws $\varnothing 5 \times 50\text{mm}$ (Part No.00055).

Attention: Suspension plate = Set → Fold in the middle at predetermined breaking point for left and right suspension plate!

3. If required for installation: remove the front sections.
4. In the body, unlock the lower screw (suspension lock according to fig.1) on the suspension fitting, suspend the body on the room wall and secure the lock again.

Alignment with the spirit level via the following steps with a screwdriver size PZ2 (see also fig. 1):

5. Make a horizontal correction using the upper height-adjusting screw on the suspension fitting.
6. Adjust the distance from the room wall or the vertical inclination using the centre depth-adjusting screw.
7. Close the rear panel notches with caps. Reinstall and align the front sections if necessary.
Clip the decorative caps onto the door hinges.
8. Fit the handles. To do this, use a furniture handle screw M4x23mm (Part No.51251).



Warning: For reasons of load-bearing capacity, align and load all fittings evenly.
Observe the maximum load capacity of the suspension units!
If hanging lowboards are not fitted correctly in accordance with the assembly instructions, there is a risk of the units falling down unintentionally!



Figure 1: Suspension fitting adjustment & suspension lock





Figure 2: Drilling dimensions of outer or upper edge of body for suspension rails

All information in mm!



Brackets only on the exterior flap compartment

